

# *The Arch Setup Instructions*

To begin, you're going to gather all 9 (20") arch dowels, 18 bolts and two arch sides.



Next, insert the bolts into holes closest to the handles. The arch side pieces need to be horizontal. Then insert a dowel into each bolt. (Make sure to leave the dowels loose).



Next add the other side of the arch to the dowels (Make sure not to tighten the bolts until all the dowels are attached to both sides of the arch pieces).



Once all your arch dowels are attached to both arch side pieces, then you are ready to tighten all the bolts securely.

