

The Cube Setup Instructions

First, gather two cube sides, one cube top, 8 cube dowels(18") and 16 bolts.



Insert bolts(very loosely) on the bottom of the cube(the bottom of the cube side with the insert indentation slots on top, facing inward towards each other)



Then, attach the other side of the cube to the dowels with the bolts(very loosely).



Next insert the remaining dowel rods with the bolts(very loosely).



Lastly, slide the cube top into the slot inserts at the top of the cube

